

INTIMIDATOR

SPOT 475ZX

FIRMWARE UPDATE PROCEDURES

These firmware updates provide bug fixes and improvements to your product experience. Please review all information below prior to updating your fixture.

| <u>Software Version</u> | <u>Description</u> |
|-------------------------|--|
| 1.22 | Initial release |
| 2 | Added ability to set color from the RFC-XL rotary color picker |

Special Notes:

1. Do not use a thumb drive greater than 32GB.
2. The thumb drive must be formatted to FAT32.
3. Only 1 fixture can be updated at a time (no daisy-chaining).

Firmware Update Instructions:

1. Download the ZIP file onto your computer and extract the folder.
2. Transfer the contents of the ZIP file onto the USB-C thumb drive.
3. Power on the fixture and let it boot up completely.
4. Go to “SYSINFO” on the main menu and note the current firmware version.
5. Insert the USB drive into the USB-C port.
6. The “Advanced Settings” window will automatically open showing “USB Update”.
7. Select YES by pressing UP/DOWN, then press “ENTER”
8. A window with the software file name will appear. Press “ENTER” to highlight “YES” then press “ENTER”.
9. The display will say “USB Update. Wait...” and the firmware will update.
10. Once the upload is complete the fixture will reboot itself (approximately 1 min).
11. Remove the USB thumb drive.

