



## Foot-C 2

Foot-C 2 is a full-featured compact DMX foot controller with up to 36 channels of control. Create and control a full light show of chases, scenes, fades, and more with just the tap of a foot! Easily change from scene to scene using the up and down pedals and achieve instant blackout with the press of a pedal. Foot-C 2 has guitar pedal-style buttons and a bright and easy-to-read LED display that shows modes, functions, and values to provide convenient and durable access to light shows. Foot-C 2 has included MIDI input for a perfectly timed show and direct audio line input triggers scenes with amazing accuracy. Foot-C 2 is designed to work with fixtures that have up to 6 channels.



# Highlights

- Full-featured compact DMX foot controller with up to 36 channels of control
- Instant blackout with just a tap of a pedal
- Easily change from scene to scene using the up and down pedals
- Designed to work with fixtures that have up to 6 channels
- Guitar pedal-style buttons provide convenient and durable access to light shows
- Create and control a full light show of chases, scenes, fades, and more
- Built-in Tap Sync, Auto, and Sound modes to match the feel and tempo of any show
- Bright and easy-to-read LED displays show modes, functions, and values
- Included MIDI input for a perfectly timed show
- Direct audio line input triggers scenes with amazing accuracy
- Fits best in the CHS-25 VIP Gear Bag

## Specifications

- DMX Channels: 36
- DMX Connectors: 3-pin XLR
- Input Voltage: 12 VDC, 1 A (external power supply: 100 to 240 VAC, 50/60 Hz)
- Weight: 4 lb (1.9 kg)
- Size: 7.2 x 14.2 x 2.6 in (183 x 360 x 66 mm)
- Approvals: CE
- Audio Line in: RCA

## What's Included

- Foot-C 2
- Power Adaptor
- Warranty card
- Quick Reference Guide